Technical Information

Current revision 5 07/06/2019



C/ Plató 6, Entlo. 5º- 08021 Barcelona (Spain) Tel. (93) 238 90 90 Fax (93) 238 90 91 www.derypol.com

Hyfloc AC80

Product for water treatments

DESCRIPTION

Blend of organic and inorganic coagulants in aqueous solution.

Can be diluted in water in different proportions.

CHARACTERISTICS

Type of product : Aqueous solution
Appearance : Yellow liquid
Ionic character : Cationic
Density : 1.34 g/cm³
pH : 0.5 - 1.5
Viscosity : 0 - 1000 cP

Shelf life : We recommend not keeping the product for more than 6 months.

Note: The parameters indicated here are not necessarily the specifications of the product. These will be agreed with each customer and will be part of the contract that must be respected for each batch supplied.

APPLICATION

- The product is usually dosed as it is, although in some cases for optimum performance may be previously
 diluted with water. This dilution can be made at any concentration and with a inline mixer, a tank with a stirrer
 is not necessary.
- Coagulant for wastewater and sludge treatments from different areas (food industry, slaughterhouse, chemical industry, metalurgic, paint, etc).

Consult our technical staff in case of any doubt.

6/7/2019 EN (English) 1/2



BENEFITS

- It may replace, totally or partially, exclusively inorganic coagulants.
- Improves the water clarification.
- Effective in a wide range of pH.
- It may act as a discolouring agent in aqueous effluents with dyes.

STORAGE AND DISTRIBUTION

- The product should be kept in a covered place, the container tightly closed, protected from sunlight and within the temperature range recommended in Section 7 of the Safety Data Sheet.
- Once the container is open, avoid contamination with any other water based product and/or with strong bases.
 Check the Material Safety Data Sheet.
- Take the habitual precautions when handling a chemical product. Avoid the product to contact with eyes, skin
 or clothes.
- There is a great variety of containers. Check with our Customer Service in order to choose the most convenient one.

REGULATORY

Consult our technical staff in case of any doubt.

6/7/2019 EN (English) 2/2